

aces represent high-frequency, high-current paths. Lead lengths should be minimized to avoid high-frequency noise problems

