



**J4**  
Vdc in+ 1 2 Vdc in+ em

**EM connector**

**Emergence switch circuit**

Normally, SW1 is closed. It will be open when end user press emergence switch. It open power supply for current source.

Title		
Power for current source		
Size	Document Number	Rev
	<b>DRR-POWER</b>	1.0
Date:	Thursday, January 06, 2005	Sheet 5 of 6